

ERL MAINTENANCE SUPPORT SDN BHD

(Company No. 498574-T)









PROJECT & ENGINEERING DEPARTMENT

TRACK 11 WEIGHING TRACK PROCEDURE

Ref. No. G00.OMD.M12980.PE.1005.A

<i>Location</i>	<i>Reference</i>	<i>Rev.</i>	<i>Date</i>	<i>Page No.</i>	<i>Document Title</i>
E-MAS Offices	G00.OMD.M12980.PE.1005.A	A	11-July-16	Page 2 of 14	Track 11 Weighing Track Procedure

Release

Released:	Ham Mow Wai	Maintenance	9/8/2016	
Acknowledged:	David Thiagarajan	Quality, Environment & Documentation	27/7/16	
Acknowledged:	Norazman Abu Hassan	Rolling Stock	27/7/16	
Acknowledged:	Azerul Fahmi Mohamed	Project & Engineering	11/7/16	
Checked:	Dzulfaqr Yusoff	Project & Engineering	11/7/16	
Author:	Amir Nordin	Project & Engineering	11-7-16	
	Name	Department	Date	Signature

Amendments or additions to this procedure must be indicated with a vertical black line in the adjacent left margin.

<i>Location</i>	<i>Reference</i>	<i>Rev.</i>	<i>Date</i>	<i>Page No.</i>	<i>Document Title</i>
E-MAS Offices	G00.OMD.M12980.PE.1005.A	A	11-July-16	Page 3 of 14	Track 11 Weighing Track Procedure

Change Record and Configuration Control

A	11-July-16		New	Amir Nordin
Revision	Date		Modification	Name

<i>Location</i>	<i>Reference</i>	<i>Rev.</i>	<i>Date</i>	<i>Page No.</i>	<i>Document Title</i>
E-MAS Offices	G00.OMD.M12980.PE.1005.A	A	11-July-16	Page 4 of 14	Track 11 Weighing Track Procedure

TABLE OF CONTENTS**Page**

1	Purpose	5
2	Scope, Distribution & Access	5
3	Track 11 Weighing Track.....	5
3.1	Wiring Diagram.....	5
3.2	System Structure	5
4	Software	6
4.1	Software Installation	7
4.2	Software and Report Keeping	7
5	Operating Instructions	7
5.1	Step 1 – Log in	7
5.2	Step 2 – Choose Option & Key in the Details	8
5.3	Step 3 – Measuring the Load of Axle.....	9
5.4	Step 4 – Data Tabulated.....	11
6	Calibration and Adjustment	12
6.1	Flintec Indicator Adjustment	12
6.1.1	Fast Access Adjustment	12
6.1.2	[310] Zero Adjustment	12
6.1.3	[311] Span Adjustment	13
6.1.4	Exiting the Calibration.....	14

<i>Location</i>	<i>Reference</i>	<i>Rev.</i>	<i>Date</i>	<i>Page No.</i>	<i>Document Title</i>
E-MAS Offices	G00.OMD.M12980.PE.1005.A	A	11-July-16	Page 5 of 14	Track 11 Weighing Track Procedure

1 Purpose

The purpose of this procedure is to provide an overview and guideline for operating and maintenance of the track 11 weighing track.

2 Scope, Distribution & Access

This procedure is applicable to all RST who are responsible to carry out the train load test. The distribution and access shall be available to all RST and PNE staff via Electronic Document Management System (EDMS) and through E-MAS portal.

3 Track 11 Weighing Track

The track 11 weighing track is to measure the load of train. The load will be measured by placed the each axle on the load cell. There four main components consist in this weighing track:

1. Load Cell (MWP Load Cell)
2. Weighing Indicator (Flintec FT – 10MB)
3. Programmable Logic Control (Fatek FBs – 10 MCT)
4. Desktop Computer.

AC - DC converter is used to convert 240VAC to 12VDC to supply power for PLC, and weighing indicator.

3.1 Wiring Diagram

There are three wiring diagrams for this weighing track:

1. FT – 10 Back Side Termination
2. Fatek Termination & Communication Cable
3. Line Power Diagram

The said wiring diagrams reference number is (G00.OMD.M12980.PE.1002.A).

3.2 System Structure

The following structure is shown how the system works.

Location	Reference	Rev.	Date	Page No.	Document Title
E-MAS Offices	G00.OMD.M12980.PE.1005.A	A	11-July-16	Page 6 of 14	Track 11 Weighing Track Procedure




Figure 3.2 Track 11 System Structure

4 Software

The track 11 weighing track software is created by using Beijer software. On the back side of Dekstop Computer, there is one dongle for this Beijer software license. The Beijer software shall operate together with dongle.

The copy of Beijer software can be downloading from www.beijerelectronics.com/ftp with download code "ixruntime".




Figure 4.0 Beijer Dongle

Location	Reference	Rev.	Date	Page No.	Document Title
E-MAS Offices	G00.OMD.M12980.PE.1005.A	A	11-July-16	Page 7 of 14	Track 11 Weighing Track Procedure

4.1 Software Installation

There are 4 main folders for the software, the folders are listed below:

1. Klia_Express_Runtime
2. Wheel_Load_Tester_Print_Screen
3. Wheel_Load_Tester_Report
4. Klia_Express_1680x1024

The point number 1 to 3 shall be copy together to operate the software. Point number 4, is used to edit the software.




Figure. 4.1 The software folders

Create a new folder and paste point number 1, 2 and 3 together in the folder. To create shortcut for running the application, click Klia_Express_Runtime klia_express > Klia_Express(application) and paste at the desktop.

The data loggers can be discover at Klia_Express_Runtime > klia_express > Project Files > DatabaseExport > Data Loggers.

4.2 Software and Report Keeping

The end user is recommended to back up the operating software and measurement data for safe keeping. It shall be kept in separate location or system as backup.

5 Operating Instructions

Users may refer to the training slide (doc number: G00.OMD.M12980.PE.1003.A) prior operating the machine. Below are the instructions for operating the machine as depicted in said training slide with detail explanation.

5.1 Step 1 – Log in



Open the software by double click at the load tester icon. Click to the login icon . The username and password are shown below:

	Username	Password
1	user	klia123
2	administrator	erladmin

Location	Reference	Rev.	Date	Page No.	Document Title
E-MAS Offices	G00.OMD.M12980.PE.1005.A	A	11-July-16	Page 8 of 14	Track 11 Weighing Track Procedure




Figure 5.1.1 The main display




Figure 5.1.2 The log – in display

5.2 Step 2 – Choose Option & Key in the Details

Two options can be selected either two load cells function or four load cell function. The software will request to the user to write the details (eg. Load Test with Air or Load Test without Air) and the train number. Once the detail has been filled, press ENTER.

Location	Reference	Rev.	Date	Page No.	Document Title
E-MAS Offices	G00.OMD.M12980.PE.1005.A	A	11-July-16	Page 9 of 14	Track 11 Weighing Track Procedure



Figure 5.2.1 Selected Options





Figure 5.2.2 Information Box

5.3 Step 3 – Measuring the Load of Axle

Place the selected train axle on the load by aligning the train using shunting vehicle. The weight indicator panels (Flintec FT – 10Mb) and green box on computer screen will show the actual axle load value. The user need to click save button, the recorded value from the green box will transfer into blue box. The blue box will turn to red for indicate which side is heavier.

Location	Reference	Rev.	Date	Page No.	Document Title
E-MAS Offices	G00.OMD.M12980.PE.1005.A	A	11-July-16	Page 10 of 14	Track 11 Weighing Track Procedure



5.3.1 The reading box on the screen

No.	Details
1	Axle Number
2	Weight difference between side 1 and side 2
3	Percentage reading for axle
4	Percentage reading for bogie
5	EMB – End Motor Bogie JMB – Jacob Motor Bogie JTB – Jacob Trailer Bogie




Figure 5.3.2 The description button for the screen

Location	Reference	Rev.	Date	Page No.	Document Title
E-MAS Offices	G00.OMD.M12980.PE.1005.A	A	11-July-16	Page 11 of 14	Track 11 Weighing Track Procedure

5.4 Step 4 – Data Tabulated

Once the entire axle's load measurement being recorded, below table will be tabulated. A red box appearance will indicate that the recorded value is out of range. There are two types of table:

1. Table for Axle Load
2. Table for Bogie Load

Axle No:	1	2	3	4	5	6	7	8	9	10
Wheel load side 1	5153kg	5319kg	5910kg	5786kg	4996kg	4879kg	6302kg	6486kg	5391kg	5523kg
Wheel load side 2	5689kg	5497kg	6563kg	6646kg	5273kg	5253kg	6158kg	5968kg	5328kg	5219kg
Absolute value of wheel load deviation	536kg	178kg	653kg	860kg	277kg	374kg	144kg	518kg	63kg	304kg
Axle load	10842kg	10816kg	12473kg	12432kg	10269kg	10132kg	12460kg	12454kg	10719kg	10742kg
Wheel load deviation on one axle	4.94%	1.65%	5.24%	6.92%	2.70%	3.69%	1.16%	4.16%	0.59%	2.83%
Admissible tolerance	5%	5%	5%	5%	5%	5%	5%	5%	5%	5%

TOLERANCE (AXLE)
-Box will turn red if reading exceeds 5%

Figure 5.4.1 The tabulated data for axle

Bogie No:	1	2	3	4	5
Sum of wheel loads per bogie	21658kg	24905kg	20401kg	24914kg	21461kg
-1. Value	5.07%	6.74%	3.39%	1.18%	2.94%
-2. Value	4.83%	7.07%	4.34%	4.18%	2.73%
Maximum wheel load deviation	5.07%	7.07%	4.34%	4.18%	2.94%
Admissible tolerance	5%	5%	5%	5%	5%

Sum of wheel loads per train : 113339kg

TOLERANCE (BOGIE)
-Box will turn red if reading exceeds 5%

<i>Location</i>	<i>Reference</i>	<i>Rev.</i>	<i>Date</i>	<i>Page No.</i>	<i>Document Title</i>
E-MAS Offices	G00.OMD.M12980.PE.1005.A	A	11-July-16	Page 12 of 14	Track 11 Weighing Track Procedure

6 Calibration and Adjustment

A verification or calibration process is proposed to be executed annually as to ensure the system accuracy within 2% tolerance. These processes shall be documented.

Only Zero Adjustment can be executed as necessary and no recording required. However, if zero drift is beyond 50kg it this recommended that verification to be executed immediately.

6.1 Flintec Indicator Adjustment

All instructions for the Flintec Indicator can be found at **FT – 10 Technical Manual, Rev 2.1** (doc number: G00.OMD.M12980.PE.1001.A). The basic meaning of the button keys on the indicator is shown as below:






				
Exit without saving	Advancing next parameter	Select the digit will be changed	Changing parameter value or increasing the blanking digit	Enter

Figure 6.1.1 The Flintec Indicator Button Description

6.1.1 Fast Access Adjustment

The below steps is for the fast access to the calibration function. On the sub – block, the maintenance can perform either [310] zero adjustment or [311] span adjustment.








Display	Operation
[123.456 kg]	Press  key until [PASSWr] prompts seen.
[PASSWr]	Press  +  +  keys sequentially.
[---]	Press  key for confirm.
[310]	Zero Adjustment parameter.
"Calibration"	Press  key to start zero adjustment. Or press  key to access span calibration without zero adjustment.

Figure 6.1.1.1 Steps for Flintec Indicator Adjustment

6.1.2 [310] Zero Adjustment

The zero adjustment is used to set position of the scale to prevent wrong weighing due to zero drifts. This is required if the indicated value is deviate from reading "0kg" during no load being applied onto the load cell. Follow the steps below:

Location	Reference	Rev.	Date	Page No.	Document Title
E-MAS Offices	G00.OMD.M12980.PE.1005.A	A	11-July-16	Page 13 of 14	Track 11 Weighing Track Procedure





1. Press  at the [**310**] prompt to start the zero adjustment.
2. At the [**ZEro.CA**] prompt, remove any weight on the platform, then press .
3. The terminal automatically starts to capture zero and the [**WAit**] message indicating the operation is in progress.
4. At the [**SAVe**] prompt press  key to continue to the next parameter or press  key to exit without saving the calibration.

Figure 6.1.2.1 Steps for Zero Adjustment

6.1.3 [311] Span Adjustment

The span adjustment is required to synchronize the load on the load cell with the indicator reading. Due to the limitation of calibration / verification equipment capability, the span adjustment load to be applied are between 2000kg to 5000kg and the steps are listed below:

1. Assemble the jigs, tools and instrument according to Figure 6.1.3.1.
2. Impose some load to the assembly by pumping the hydraulic piston.
3. Keep on adjusting the imposed load to nearly 5000kg by referring to reference load cell.
4. Proceed with the process depicted in Figure 6.1.3.2 for span adjustment on Flintec indicator.




Figure 6.1.3.1 The apparatus arrangement

Location	Reference	Rev.	Date	Page No.	Document Title
E-MAS Offices	G00.OMD.M12980.PE.1005.A	A	11-July-16	Page 14 of 14	Track 11 Weighing Track Procedure





1. Press <  > at the [311] prompt to start the span adjustment.
2. At the [XXXXXX] prompt, the test weight value will be used for the calibration seen on the display. If the value of the test weights that will be used is different from the value shown on the display, type the new value via tare and zero keys. A minimum of 20% of scale capacity is necessary for calibration; FLINTEC recommends 50 to 100%. A calibration error will result if insufficient weight is used.
3. Place the test weights or another practical weight on the scale.
4. Press  to start span calibration. [Wait] message will be shown on the display 10 s while span calibration is being performed.
5. At the [SAve] prompt press  key to continue to the next parameter or press  key to exit without saving the calibration.

Figure 6.1.3.2 Steps for Span Adjustment

6.1.4 Exiting the Calibration

The below steps is to perform exit from the calibration.







- If you press  key on which parameter you are, you will get out of the active sub-block and reach the next sub-block. If you press  key again, you will get out of the active block and reach the next main block. If you press  key once again, the [SAve] message appears on the display.
- Here you can press  key to save the changes into the memory,
 - or you can press  key to store the changes until the power goes off,
 - or you can press  key to abort changes.
- [Wait] message will be seen on the display for a little while, and automatically get back to weighing mode. Especially for legal metrological usage, please don't forget to turn the power off and "OFF" position the calibration DIP switch to start operation.

Figure 6.1.4.1 Steps for Exiting the Calibration